

# Sample 12-5

## 画像復元

主-双対近接分離法 (PDS)

画像処理特論

村松 正吾

動作確認: MATLAB R2023a

## Image restoration

Primal-dual splitting (PDS)

Advanced Topics in Image Processing

Shogo MURAMATSU

Verified: MATLAB R2023a

## 準備

(Preparation)

```
clear
close all
import msip.download_img
msip.download_img
```

```
kodim01.png already exists in ./data/
kodim02.png already exists in ./data/
kodim03.png already exists in ./data/
kodim04.png already exists in ./data/
kodim05.png already exists in ./data/
kodim06.png already exists in ./data/
kodim07.png already exists in ./data/
kodim08.png already exists in ./data/
kodim09.png already exists in ./data/
kodim10.png already exists in ./data/
kodim11.png already exists in ./data/
kodim12.png already exists in ./data/
kodim13.png already exists in ./data/
kodim14.png already exists in ./data/
kodim15.png already exists in ./data/
kodim16.png already exists in ./data/
kodim17.png already exists in ./data/
kodim18.png already exists in ./data/
kodim19.png already exists in ./data/
kodim20.png already exists in ./data/
kodim21.png already exists in ./data/
kodim22.png already exists in ./data/
kodim23.png already exists in ./data/
kodim24.png already exists in ./data/
See Kodak Lossless True Color Image Suite
```

## 問題設定

(Problem settings)

$$\hat{\mathbf{s}} = \arg \min_{\mathbf{s}} \frac{1}{2} \|\mathbf{v} - \mathbf{D}\mathbf{s}\|_2^2 + \lambda \|\mathbf{s}\|_1, \quad \text{s.t. } \mathbf{D}\mathbf{s} \in [a, b]^2$$

- $\mathbf{D} = \begin{pmatrix} 2 & 1 \\ 3 & 3 \end{pmatrix}: \mathbb{R}^2 \rightarrow \mathbb{R}^1$
- $\mathbf{v} = \frac{1}{2} \in \mathbb{R}^1$
- $\lambda \in [0, \infty)$
- $\mathbf{s} \in \mathbb{R}^2$
- $a, b \in \mathbb{R}$


```
D = [2 1]/3;  
v = 0.5;  
a = -0.5;  
b = 0.0;
```

## 関数プロット

(Function plot)

```
% Function settings  
f = @(s0,s1) 0.5*(v-(D(1)*s0+D(2)*s1)).^2;  
g = @(s0,s1) (abs(s0)+abs(s1));  
% Variable settins  
s0 = linspace(-1,1,21);  
s1 = linspace(-1,1,21);  
[S0,S1] = ndgrid(s0,s1);  
F = f(S0,S1);  
G = g(S0,S1);  
% Surfc plot of the fidelity  
figure(1)  
hf = surf(s0,s1,F);  
hf(1).FaceAlpha = 0.125;  
hf(1).FaceColor = 'green';  
hf(1).EdgeAlpha = 0.25;  
hf(2).LineWidth = 1;  
set(gca, 'YDir', 'reverse');  
hold on  
% Surfc plot of the regularizer  
hg = surf(s0,s1,G);  
hg(1).FaceAlpha = 0.125;  
hg(1).FaceColor = 'blue';  
hg(1).EdgeAlpha = 0.25;  
hg(2).LineWidth = 1;  
xlabel('s_1')
```

```
ylabel('s_0')
hold off
```



## パラメータ設定

(Parameter settings)

```
lambda = 0.2;
gamma1 = 0.4;
nitters = 20;
```

## 制約付き $\ell_1$ -ノルム正則化最小自乗法による近似

( $\ell_1$  -norm-regularized least square method with constraint)

$$\hat{\mathbf{s}} = \arg \min_{\mathbf{s}} \frac{1}{2} \|\mathbf{v} - \mathbf{D}\mathbf{s}\|_2^2 + \lambda \|\mathbf{s}\|_1, \quad \mathbf{D}\mathbf{s} \in [a, b]^2$$

主-双対近接分離法に帰着させる. (Reduced to a primal-dual splitting method)

$$\hat{\mathbf{x}} = \arg \min_{\mathbf{x} \in V} f(\mathbf{x}) + g(\mathbf{x}) + h(\mathbf{L}\mathbf{x})$$

- $\mathbf{L} \in \mathbb{R}^{K \times L}$
- $f(\cdot), g(\cdot) \in \Gamma_0(\mathbb{R}^L), h(\cdot) \in \Gamma_0(\mathbb{R}^K)$ : Convex functions


- $f(\cdot)$  is differentiable (  $\beta$ -Lipschitz continuous)
- $\Gamma_0(\mathbb{R}^L)$  : Set of proper semi-lower-continuous convex functions

### 【Example】

- $f(s) = \frac{1}{2} \|v - Ds\|_2^2$
- $g(s) = \lambda \|s\|_1$
- $h(Ls) = \iota_{[a,b]^2}(Ds)$

### 関数プロット (Function plot)

```
% Function setting
fg = @(s0,s1) 0.5*(v-(D(1)*s0+D(2)*s1)).^2 + lambda*(abs(s0)+abs(s1));
% Surfc plot of cost function f+g
figure(2)
J = fg(S0,S1);
hf = surfc(s0,s1,J);
hf(1).FaceAlpha = 0.25;
hf(1).EdgeAlpha = 0.25;
hf(1).EdgeColor = 'interp';
hf(2).LineWidth = 1;
set(gca, 'YDir', 'reverse')
ylabel('s_0')
xlabel('s_1')
zlabel('f(s)+g(s)')
hold on
```



## 主-双対近接分離法

(Primal-dual splitting method)

1. Initialization:  $\mathbf{x}^{(0)}, t \leftarrow 0$
2. Primal:  $\mathbf{x}^{(t+1)} \leftarrow \text{prox}_{\gamma_1 g}(\mathbf{x}^{(t)} - \gamma_1 (\nabla_x f(\mathbf{x}^{(t)}) + \mathbf{L}^T \mathbf{y}^{(t)}))$
3. Dual:  $\mathbf{y}^{(t+1)} \leftarrow \text{prox}_{\gamma_2 h^*}(\mathbf{y}^{(t)} + \gamma_2 \mathbf{L}(2\mathbf{x}^{(t+1)} - \mathbf{x}^{(t)}))$
4. If a stopping criteria is satisfied then finish, otherwise  $t \rightarrow t + 1$  and go to Step 2.

### 【Example】

- $\nabla_x f(\mathbf{x}) = \mathbf{D}^T(\mathbf{D}\mathbf{x} - \mathbf{v})$
- $\text{prox}_{\gamma \lambda \|\cdot\|_1}(\mathbf{x}) = \mathcal{T}_{\gamma \lambda}(\mathbf{x}) = \text{sign}(\mathbf{x}) \odot \max(\text{abs}(\mathbf{x}) - \gamma \lambda \mathbf{1}, \mathbf{0})$
- $\text{prox}_{\gamma C^*}(\mathbf{y}) = \mathbf{y} - \gamma \mathcal{P}_C(\gamma^{-1} \mathbf{y})$

ただし, (where)  $C = [a, b]^N$

$$\mathcal{P}_{[a,b]^N}(\mathbf{x}) = \min \{ \max \{ \mathbf{x}, a \}, b \}$$

ソフト閾値処理 (Soft-thresholding)

```
softthresh = @(x,t) sign(x).*max(abs(x)-t,0);
```

初期化 (Initialization)

```
sp = 2*rand(2,1)-1; % in [-1,1]^2
```

ステップサイズ  $\gamma_2$  の設定 (Settings for stepsize  $\gamma_2$ )

```
beta = D*D';  
tau2 = D*D';  
gamma2 = 1/(1.05*tau2)*(1/gamma1-beta/2);  
assert((1/gamma1 - gamma2*tau2) > beta/2, 'Step size condition is violated.')
```


主双対近接分離法 (Prima-dual splitting method)

```
sf0 = -1:.01:1;  
sf1 = -1:.01:1;  
[Sf0,Sf1] = ndgrid(sf0,sf1);  
ic = @(x1,x2) (D(1)*x1+D(2)*x2)>=a & (D(1)*x1+D(2)*x2)<=b;  
C = repmat(ic(Sf0,Sf1),[1 1 3]);  
hc = surf(sf0,sf1,zeros(size(C,1),size(C,2)),double(C));  
hc.EdgeColor = 'interp';  
hc.EdgeAlpha = 0.25;  
hc.FaceAlpha = 0.25;  
y = D*sp;  
for idx=0:niters-1  
    % Preious state  
    s(1,1) = sp(1); % s0  
    s(2,1) = sp(2); % s1  
    % Primal  
    sg = sp-gamma1*D'*((D*sp-v)+y);  
    sc = softthresh(sg,gamma1*lambda);  
    % Dual  
    u = y + gamma2*D*(2*sc-sp);  
    y = u - gamma2*min(max(u/gamma2,a),b);  
    % Current state  
    s(1,2) = sc(1); % s0  
    s(2,2) = sc(2); % s1  
    % Quiver plot  
    xp = s(2,1);  
    yp = s(1,1);  
    xn = s(2,2);  
    yn = s(1,2);  
    hp = quiver(xp,yp,xn-xp,yn-yp);  
    hp.Marker = 'o';  
    hp.ShowArrowHead = 'on';  
    hp.MaxHeadSize = 120;  
    hp.MarkerSize = 6;  
    hp.MarkerEdgeColor = 'r';  
    hp.Color = 'r';  
end
```

```

hp.LineWidth = 2;
% Update
sp = sc;
end
hold off

```



## パラメータ設定

(Parameter settings)

- sgm: ノイズ標準偏差  $\sigma_w$  (Standard deviation of noise)

```

% Parameter settings
lambda = 10^-2.4

```

```

lambda = 0.0040

```

```

gamma1 = 10^-2.4

```

```

gamma1 = 0.0040

```

```

sgmuint8 = 10;
sgm = sgmuint8/255;
nitters = 80;

```

## 画像の読込

(Read image)

```
u = rgb2gray(im2double(imread('./data/kodim23.png')));
```

## 観測画像

(Observation image)

- $\mathbf{v} = \mathbf{P}\mathbf{u} + \mathbf{w}$
- $\mathbf{w} \sim \text{Norm}(\mathbf{w} | \boldsymbol{\mu}_w = \mathbf{0}, \sigma_w^2 \mathbf{I})$

```
% Definition of measurment process
psf = fspecial('motion',21,11);
measureproc = @(x) imfilter(x,psf,'conv','circular');
% Adjoint process of the measurment process
measureadjp = @(x) imfilter(x,psf,'corr','circular');
% Simulation of AWGN
v = imnoise(measureproc(u),'gaussian',0,sgm^2);
```

## 全変動正則化

(Total-variation regularization)

PDS の応用例として全変動正則化による画像復元を行う。(As an application of PDS, total variation regularization is applied to image restoration.)

### 問題設定 (Problem settings)

$$\hat{\mathbf{u}} = \arg \min_{\mathbf{u} \in [0,1]^N} \frac{1}{2} \|\mathbf{v} - \mathbf{P}\mathbf{u}\|_2^2 + \lambda \|\mathbf{u}\|_{\text{TV}}$$

⇓

$$\hat{\mathbf{u}} = \arg \min_{\mathbf{u} \in \mathbb{R}^N} \frac{1}{2\lambda} \|\mathbf{v} - \mathbf{P}\mathbf{u}\|_2^2 + \iota_{[0,1]^N}(\mathbf{u}) + \|\nabla \mathbf{u}\|_{1,2}$$

### アルゴリズム (Algorithm)

1. Initialization:  $\mathbf{u}^{(0)}, \mathbf{y}^{(0)}, t \leftarrow 0$
2.  $\mathbf{u}^{(t+1)} \leftarrow \mathcal{P}_{[0,1]^N}(\mathbf{u}^{(t)} - \gamma_1(\lambda^{-1} \mathbf{P}^T(\mathbf{P}\mathbf{u}^{(t)} - \mathbf{v}) + \nabla^T \mathbf{y}^{(t)}))$
3.  $\mathbf{y}^{(t+1)} \leftarrow \text{prox}_{\gamma_2(\|\cdot\|_{1,2})^*}(\mathbf{y}^{(t)} + \gamma_2 \nabla(2\mathbf{u}^{(t+1)} - \mathbf{u}^{(t)}))$
4. If a stopping criteria is satisfied then finish, otherwise  $t \rightarrow t + 1$  and go to Step 2.

ただし, (where)



- $\text{prox}_{\gamma \|\cdot\|_{1,2}^*}(\mathbf{x}) = \mathbf{x} - \gamma \text{prox}_{\gamma^{-1} \|\cdot\|_{1,2}}(\gamma^{-1} \mathbf{x})$
- $\left[ \gamma \text{prox}_{\gamma^{-1} \|\cdot\|_{1,2}}(\gamma^{-1} \mathbf{x}) \right]_{\mathcal{J}_n} = \mathbf{x}_{\mathcal{J}_n} \odot \max \left\{ \mathbf{1} - \frac{1}{\|\mathbf{x}_{\mathcal{J}_n}\|_2} \mathbf{1}, 0 \right\}$  (Soft-thresholding for magnitude of  $\nabla \mathbf{x}$ )
- $\gamma_1^{-1} - \gamma_2 (\sigma_{\max}(\nabla))^2 \geq (2\lambda)^{-1} (\sigma_{\max}(\mathbf{P}))^2$

### 勾配フィルタ (Gradient filter)

```
g0 = fspecial('sobel'); % Vertical difference
g1 = rot90(g0); % Horizontal difference
gradproc = @(x) cat(3,imfilter(x,g0,'conv','circ'),imfilter(x,g1,'conv','circ'));
gradadjp = @(x) imfilter(x(:,:,1),g0,'corr','circ') +
imfilter(x(:,:,2),g1,'corr','circ');
```

### 初期化 (Initialization)

```
up = v;
yp = gradproc(v);
```

### ステップサイズ $\gamma_2$ の設定 (Settings for stepsize $\gamma_2$ )

```
nPoints = 2.^nextpow2(size(v));
beta = max(abs(fftn(psf,nPoints)).^2,[],'all')/lambda; % ( $\sigma_{\max}(\mathbf{P})$ )^2/ $\lambda$ 
tau2 = max(abs(fftn(g0,nPoints)).^2,[],'all'); % ( $\sigma_{\max}(\mathbf{G})$ )^2
gamma2 = 1/(1.05*tau2)*(1/gamma1-beta/2);
assert((1/gamma1 - gamma2*tau2) > beta/2,...
['Step size condition is violated.  $\gamma_1$  must be less than ' num2str(2/beta)])
```

### 主-双対近接分離法 (Primal-dual splitting method)

```
for idx=0:niters-1
    % Primal step
    ug = measureadjp(measureproc(up)-v);
    uc = min(max(up-gamma1*(ug/lambda + gradadjp(yp)),0),1);
    % Dual step
    yt = yp + gamma2*gradproc(2*uc - up);
    yc = yt - magshrink(yt); % MAGSHRINK is defined at the end of this script
    % Update
    up = uc;
    yp = yc;
end
```

### 復元画像


(Restored image)

```
r = uc;
```

## 画像表示

(Image show)

```
figure(1)
imshow(u);
title('Original image u')
```



```
figure(2)
imshow(v)
title(sprintf('Noisy image v : PSNR = %5.2f [dB]',psnr(u,v)))
```

Noisy image v : PSNR = 23.70 [dB]



```
figure(3)
imshow(r)
```

```
title(sprintf('Restored image r /w TV-regularization: PSNR = %5.2f [dB]',psnr(u,r)))
```

Restored image r /w TV-regularization: PSNR = 25.00 [dB]



## 振幅ソフト閾値関数

(Magnitude soft-thresholding)

```
function y = magshrink(x)
    Gy = x(:,:,1);
    Gx = x(:,:,2);
    Gmag = imgradient(Gx,Gy);
    map = max(1 - 1./Gmag,0);
    y = x.*map;
end
```

© Copyright, Shogo MURAMATSU, All rights reserved.